

Running Two Copies of EASYLABEL using Sandboxie

When designing label formats, it can be helpful to have two label formats on the screen. Label designers can reference one label format while creating a second similar label format; and even copy fields from one label onto the other. This requires two instances of EASYLABEL, which currently is not possible with EASYLABEL alone. However, we would like to make you aware of an easy workaround using a program named Sandboxie, which makes it possible to run two instances of EASYLABEL. Before using Sandboxie, please be aware Tharo Systems has no relationship with its manufacturer and does not offer technical support for it.

To install Sandboxie, browse to the website www.sandboxie.com and download the free version. Once downloaded, run the installation file and follow the on-screen instructions. We also recommend you do the short tutorial that follows the installation. Installing the software and going through the tutorial usually takes around ten minutes.

To run two instances of EASYLABEL, open EASYLABEL as you normally would, right-click on the EASYLABEL shortcut and select "Run Sandboxed" from the popup menu. Now you will have two EASYLABEL windows on your screen and will be able to open label formats in each window. We recommend you only create, edit and print label formats from your original instance of EASYLABEL. Use your Sandboxed instance only for viewing and copying.